




CENTRAL BOILER  
**E-CLASSIC®**

# Furnace Base and Dimensions



E-Classic Measurements									
	A	B	C	D	E	F	G	H	I
<b>E-Classic 1450</b>	42.5"	73"	57"	47"	59"	71"	150"	5"	34"
<b>E-Classic 3250</b>	49.5"	87"	68"	54"	70"	86"	167"	5"	37"

- Measurement (F) is from firebox door to chimney inspection cover.  
 - Measurement (G) includes two 4 ft. chimney sections.

**CAUTION**  
 Do not use any combustible materials for the foundation.

Outdoor furnace must be installed on a noncombustible surface or foundation that incorporates an enclosure that will prevent supply and return lines from possible exposure to sunlight, fire, or physical damage that may be caused by an occurrence outside the outdoor furnace enclosure. Foundation may consist of concrete, crushed rock, or patio blocks.

