


Panel Radiator Install

Parts List		
Qty	p/n	Description
4	1331	1" PEX to 1" Sweat Adapter
2	1337	1/2" PEX to 1/2" Sweat Adapter
2	1341	1/2" PEX to 1/2" MIP Adapter
6	5926	1" PEX Crimp Ring
4	5927	1/2" PEX Crimp Ring
1	604	1/2" TRV Valve
1	605	1/2" LKD Valve
2	6782	Brass Diverter Tee
1	198	Ball Valve, 3/4"
2	1330	PEX Adapter, 1" x 3/4"

All Select Panel Radiators come with four plugs, mounting brackets and a small tube of Loctite® for the threads.

Vent plug is always in the opposite corner (diagonally) of the TRV valve.

Solid plug is always in the opposite corner (diagonally) of the LKD valve.



Hot Supply from Pump on Outdoor Furnace.

NOTE
Corrosion Inhibitor is required in these units to ensure that the unit does not corrode from the inside.

This valve remains open except for bleeding.

Panel Radiators		
p/n	Baseboard Equivalent	Fan Convecter Equivalent
600	6 feet	6771
601	10 feet	6777, 6774, 6775
602	14 feet	6776, 6780
603	18 feet	6779, 6773

